

Instructions for communicating with Victron inverter using the communication box

(1) Use this communication cable(comes with battery package) to connect battery's comm port and communication box's BMS-485 port. Note setting battery DIP switch according to the following picture.




Parallel DIP Switch

No. of BAT	1	2	3	4	5	6	7	8	9	10	11	12
1 PCS	1,5 ON											
2 PCS	1,5 ON	2,5 ON										
3 PCS	1,5 ON	2 ON	1,2,5 ON									
4 PCS	1,5 ON	2 ON	1,2 ON	3,5 ON								
5 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3,5 ON							
6 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3, 5 ON						
7 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1,2,3,5 ON					
8 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1, 2,3 ON	4,5 ON				
9 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1, 2,3 ON	4 ON	1,4,5 ON			
10 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1, 2,3 ON	4 ON	1,4 ON	2,4,5 ON		
11 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1, 2,3 ON	4 ON	1,4 ON	2,4 ON	1,2,4,5 ON	
12 PCS	1,5 ON	2 ON	1,2 ON	3 ON	1,3 ON	2,3 ON	1, 2,3 ON	4 ON	1,4 ON	2,4 ON	1,2,4 ON	3,4,5 ON





Note: The inverter needs to be connected to the first battery, that is, the battery pack with the 1,5 ON.

(2) Connect power cable to power communication box(Connect it to battery). Note that the voltage range is 15VDC to 60VDC.



(3) You need make a communication cable to connect inverter and communication box`s PCS-CAN port, note setting the SW is 1 on.

	Felicitysolar	Victron
CAN_H	Pin8	Pin7
CAN_L	Pin7	Pin8



(4)When they communicate successfully, the inverter will display some information about the battery.