



Truck Box

Inside Cabin

Roof

Charge Controller

BMV 712

Sys Gnd

40A Fuse

Normally Closed

battery protect BP 12/24 100

Sys Gnd

Normally Open

battery protect BP 12/24 100

Sys Gnd

Heater Pad

Sys Gnd

Temp Probe

Sys Gnd

Chassis Gnd

victron energy  
BLUE POWER  
12V 100AH  
LiFePO<sub>4</sub> battery

victron energy  
BLUE POWER  
12V 100AH  
LiFePO<sub>4</sub> battery

