



BMV700 Setup	
01. Battery Capacity	240 Ah
12. Invert Relay	ON
16. SOC Relay (Discharge floor)	50 %
17. Clear SOC Relay	60 %

MultiPlus 24/3000/70-16 Setup	
Charger Settings	
Absorption Voltage:	28.80 V (default)
Floating Voltage:	27.60 V (default)
Storage Mode:	ON (default)
Charge Current:	52A (default)
Temperature Sensor:	Installed
Inverter Settings	
Ground Relay:	OFF

TS-1600 Setup	
Load Settings -> 24-24V default settings	
(20) Output voltage:	28.8 V (out)

VE AGM Battery Setup	
Fully charge the individual batteries before placing the batteries in the battery bank.	

Cerbo GX Setup	
Battery monitor: BMV700 on VE.Direct	